

wire is fastened to some adjacent part of the assembly. these individual parts. When such provision is not made, the safety dually. Ordinarily, anchorage lips are conveniently located near system applies to any other unit which must be safety wired indivioil cap, the wire is anchored to an adjacent fillister head screw. This units are safety wired as shown in Figure 3-1. In the case of the Figure 3-1: Safetywiring oil caps, drain cocks, and valves. These

the wire is in the direction which tightens the nut on the plug. Make safetywire as short as practical and install so the pull on nector may vibrate loose or may come apart. The proper protective Under conditions of severe vibration the coupling nut of a conmeasure to prevent this is safetywiring as shown in Figure 4-I.


Figure 4-2 shows external snap ring with safety wire installed

Figure 4-3 illustrates safetywiring on a venturi.

that are single-twist safetywired. Figure 4-4 illustrates a closely spaced multiple group of fasteners

INSTRUCTION SHEET Safetywiring Pliers SAFETYTWIST ®

counteracted by tightening of the safety wire. out: any tendency of the fastener to loosen is critical fasteners that must not be allowed to back positive and proven method of securing rapidly and consistently. Safetywiring is a and will help you do reliable safetywiring (lock wiring) Your SAFETYTWIST® Pliers is a versatile tool



ο Some models have automatic spring loaded slider return.

GENERAL OPERATING PROCEDURES 12 IMPORTANT RULES

practices for fasteners with right hand threads. experienced mechanics generally follow these equipment you assemble or service. However, the safetywiring specifications that apply to Nothing outlined herein supercedes or replaces

Form 99R320 Printed in USA

- Before any screw, nut, plug, or other fastener torqued fastener to align safety wire holes. overstress. Never overtorque or loosen a is lockwired, torque it down snugly but do not
- Use the size and type of safety wire called for reuse satety wire. in the application specifications. Do not
- Open the jaws of the SAFETYTWIST[®] Pliers by slider in the center of the pliers from the hook-lock squeezing the handles together to unlock the

your other hand to lock the pliers. the slider toward the rear of the pliers with the handles together with one hand and pull Now, grip both safety wires in the jaws. Squeeze

Frame 1 c. the pliers, letting the tool spin free, as in The safety wire may now be twisted by pulling the knob and twist rod out from

the flat of your hand against the end of the knob as in Frame 1d.* The twistin may now be repeated the pliers steady with one hand and pushing Return the knob and twist rod by holding The twisting cycle

Whenever possible employ double-twist safety. side of the wire. Twist to a tightness of 4-5 wiring (see below). After threading safety wire through the hole in the fastener, pull the twist safetywiring. rame 2 for additional examples of doublecomplete revolutions per inch. Also see wire straight through so as not to skin the out-



Limit single-twist safetywiring (see below) to tangle, circle, etc.) or parts in electrical systems or parts that are difficult to reach. Also twist safetywiring. see Frame 4 for additional examples of single geometrical patterns (triangle, square, recsmall screws located in closely spaced, closed

Ċ



in the fastener. Do not let kinks develop. Do not pull the safety wire so hard that it stretches or is nicked by the edge of the hole

- Orient safety wire so the pull exerted by the wire tends to tighten the nut.
- 8. Make twists tight, even, and as taut as possible safety wire is weakened. without over-twisting to the point where the
- 10. When castellated nuts are secured with safety Twist the safety wire so the loop around the keep the loop from slipping up and over the bolt head, through the fastener. Ensure sufficient tension to resulting in undesirable slack. bolt is routed underneath the wire which passes
- aligns with the hole (within specified torque limits) until a slot selected torque range, unless otherwise speciwire, tighten the nut to the low side of the fied, and if necessary continue tightening
- Make a pigtail of 1/4" to 1/2" length (four coming a snag, as in Frame 1e. bend back or under to prevent it from betwists minimum) at the end of the wiring and
- 12. The number of nuts, bolts, or screws that may safety wire is usually the maximum. method, a group of three or a 24" length of widely-spaced bolts by the double-twist application, but as a guide when safetywiring be safetywired together is dependent on the

For further reading:

AC 65-9A Airframe & Powerplant

Documents, Washington D.C, 20402 Both available from the Superintendent of AC 43.13-1A Aircraft Inspection and Repair (FAA) Mechanics General Handbook (FAA)

Figure 2-1 illustrates several fasteners wired in series.

Figure 2-2 illustrates safety wiring of castellated nuts and studs. Figure 2-3 and 2-4 illustrates a single-threaded component safety Note that there is no loop around the nut.

wired to a housing or lug. Figure 2-5 shows the method for wiring bolts in different planes,

Wire is applied so tension is in the tightening direction

Note: All safetywiring shown in this bulletin is based on right shown in Figure 2-6, with caution to insure that wire is wrapped Where lockwire lugs are not provided, wire should be applied as tightly around the fitting.

tion for left-hand threads. hand threads. Safety wire is routed in the opposite direc-