

**STANLEY®**

**Folding Knife Closure  
Instructional**

# STANLEY

## Folding Knife Closure Instructional

### Side View




A fully extended folding knife is locked in the open position by a 'liner lock'

### $\frac{3}{4}$ Bottom View




The liner lock is a locking mechanism for opening and closing folding knives

### Bottom View



The liner lock extends into the middle of the knife closure area to prevent the front half of the knife from unintentionally closing when in use


### Bottom View



Apply force here, in the direction of the arrow as shown



To close a folding knife, you need apply pressure to the liner lock to move it out of the way to allow space for the front half of the knife fold into the handle

### Bottom View




By moving the liner lock out of the middle of the handle, you will now be able to close the knife without interference

### Bottom View Close Up



### ¾ Bottom View



With the liner lock still pressed out of the way, you are now able to start closing the front of the knife into the handle.

Once you are able to move the front of the knife towards the closed position, you can release pressure on the liner lock.



**STANLEY**

## Folding Knife Closure Instructional

Side View



A Stanley folding  
knife in the  
closed position

**STANLEY**

## Folding Knife Closure Instructional

### Video Demonstration



**STANLEY®**